



**A**UTOMOTIVE  
**S**PECIALTY  
**S**YSTEMS

# 2022+ Hyundai Santa Cruz No-Drill Light Bar Bracket

## Tools/Materials Required

-Allen Keys    -Tape Measure    -Protective Blanket/Pad    -Blue Loctite (Optional)    -Trim/Panel Tool

## WARNINGS!!

It is strongly recommended that you have someone to assist you in this process.

Do not over tighten the bolt for the clamp mount, as permanent damage to the clamp can occur.

Professional installation is strongly recommended.

Please reach out with any questions prior to attempting the installation—[sales@automotivespecialtysystems.com](mailto:sales@automotivespecialtysystems.com)

## Installation Instructions

- 1: Place a protective blanket (moving blankets work great) on the roof covering the edge of the windshield and the work area, this is to prevent scratching/damage of the paint due to dropped tools or parts.
- 2: Remove the outside mounting screw from the bracket kit. Set aside as we will need this later. (the outside screw is the one positioned furthest from the center of the vehicle)
- 3: Measure 4" from the edge of the windshield glass up the roof rail and line clamp up with that mark. HAND tighten the clamp mounting bolt until snug. You will know its tight enough if you can rock the vehicle left to right utilizing the clamp and the clamp does not move. **DO NOT OVER TIGHTEN—This will void any warranty.**
- 4: Repeat Step 3 for the other side of the vehicle.
- 5: Make sure that the inside mounting screw is loose to allow the bracket to move freely as this will greatly help in attaching the lightbar. With an assistant, line up the light bar with the mounting holes in the bracket and mount using hardware supplied with your light bar. Do not tighten all the way.
- 6: With the lightbar loosely mounted, reinstall the outside bracket mounting screw, tighten all the way down.
- 7: Tighten the inside mounting screw.
- 8: Tighten the mounting bolt for the lightbar.
- 9: Using the panel tool, remove the windshield trim for whichever side you intend on routing your wires down, route wires through channel to under-hood area and reinstall windshield trim. At this point you will make your electrical connections

## Warranty/Disclaimer

Bracket kit is warranted against manufacturers defect for 30 days after purchase. Please inspect thoroughly upon arrival so that any shipping related damages can be addressed in a timely manner. Improper installation such as overtightening of fasteners will void this warranty. This product is for offroad use only. Automotive Specialty Systems LLC claims no liable for vehicle damage or legal penalty through the use, misuse, installation of this product.

The installation and use of this product is done solely at the end users discretion.